


### Step 1.

Remove the tube[s] from the box & locate the coupling body & insert parts as shown below.



### Step 2.

The extension tube "clicks" in between these two parts as & when needed, giving you extra tube length.

